

**SOCOCLEAN AF** is an anti foam additive for aqueous degreaser baths as **SOCOCLEAN A3432** or **SOCOCLEAN UCA/UCS**, when used by spraying.

## ***DIRECTIONS FOR USE***

- The usual dosage is 1 per ten thousand (0.01%) for degreasers at temperature of 25°C to 80°C.
- Add **SOCOCLEAN AF** at room temperature.
- Ensure, when introducing **SOCOCLEAN AF**, to homogenize the bath before use.
- **SOCOCLEAN AF** has to be used only during the installation of the bath. However it may be added during the bath maintenance, respecting the dosage of 1 per ten thousand (0.01%), if excessive foam is found.
- Respect strictly the dosage (one 100 ml bottle for a 1000 liters bath) in order to ensure product performance.

## ***TECHNICAL CHARACTERISTICS***

Appearance ..... liquid  
Colour ..... white  
Specific gravity ..... 1.0  
pH ..... (pure) 8

## ***PRECAUTIONS FOR USE AND STORAGE***

Store at room temperature.

For more information regarding the danger of the product, please consult the product safety data sheet according to local regulation.

For professional use only.

**This technical data sheet replaces and cancels the previous one.**

The above details have been compiled to the best of our knowledge. They have, however, an indicative value only and we therefore make no warranties and assume no liability in connection with any use of this information, particularly if a third party's rights are affected by the use of our products. The above information has been compiled based upon tests carried out by SOCOMORE. All data is subject to change as Socomore deems appropriate. The data given is not intended to substitute for any testing you must conduct in order to determine the suitability of the product for your particular purposes. Please check your local legislation applicable to the use of this product. Should you need any further information please contact us.