

Approvals and conformities

AIRBUS	IPS 09-04-001-01 / AIPI 09-01-003
AIRBUS HELICOPTERS	ECA 3126
ROLLS-ROYCE	CSS204 TYPE A
SAFRAN	IN1500 (conform on ML 340, Stainless Steel & Titanium)

SOCOCLEAN AQUAFORTE is a low VOC, water-based alternative to solvent aircraft cleaners for general cleaning and degreasing of metallic and composite substrates in manufacturing and maintenance operations.

Sococlean Aquaforte is a water-based cleaning product designed to provide effective surface cleaning and to eliminate oils, soils, cutting fluids, and sealant residues. It is free of soda and potash, phosphates, nitrites, phenols, and borates. It was designed to replace traditional fast evaporating solvents such as MEK, Acetone, IPA, and other solvent-based degreasers.

- Non-toxic, non-flammable and non-hazardous classification
- Eliminates hazardous transport, storage, and logistic issues associated with transporting and storing flammable liquid solvents
- Adapted for working in confined spaces
- Compatible with metallic, composite, and plastic substrates
- Available in both bulk liquid and presaturated wipe formats

USES

SOCOCLEAN AQUAFORTE is a water-based alternative to solvent cleaners for surface cleaning and degreasing in manufacturing, fabrication and maintenance operations in aerospace and other industries.

SOCOCLEAN AQUAFORTE provides effective cleaning and degreasing along with general workshop soils.

Can be used on metals, composites and thermoplastics including PC-polycarbonates (ASTM F484) & PMMA- polymethyl methacrylate (ASTM F484).

DIRECTIONS FOR USE

Sococlean Aquaforte may be used to remove a wide range of shop contaminants in manufacturing, fabrication, and maintenance operations in aerospace and other industries. It is a wipe-on/wipe-off cleaner.

For best results, use a presaturated wipe or clean rag saturated with Sococlean Aquaforte. Use a clean side of the wipe for each pass across the substrate. For difficult contaminants, apply a thin film of Sococlean Aquaforte and allow to sit for 1-2 minutes to dislodge the contamination. Use a dry, lint-free wipe to ensure thorough removal of any contaminants and residual solvent from the substrate.

For use in an immersion bath, ensure that the bath pH remains between 7.0-8.5. Dispose of the bath if the pH measures outside of this range.

PRECAUTIONS FOR USE AND STORAGE

The shelf life of Sococlean Aquaforte is 24 months from date of manufacture when stored below 37°C (100°F) in the original, unopened container. The shelf life of Sococlean Aquaforte presaturated wipe formats is 12 months from date of packaging when stored below 37°C (100°F) in the original, unopened container. Keep opened containers sealed when not in use to prevent contamination.

Sococlean Aquaforte does not require any special handling precautions, but it is recommended to use personal protective equipment as a precaution. Safety glasses are recommended when eye contact may occur.

For more information regarding the danger of the product, please consult the product safety data sheet according to local regulation. For professional use only.

This technical data sheet replaces and cancels the previous one.

The above details have been compiled to the best of our knowledge. They have, however, an indicative value only and we therefore make no warranties and assume no liability in connection with any use of this information, particularly if a third party's rights are affected by the use of our products. The above information has been compiled based upon tests carried out by SOCOMORE. All data is subject to change as SOCOMORE deems appropriate. The data given is not intended to substitute for any testing you must conduct in order to determine the suitability of the product for your particular purposes. Pictures are not contractual. Please check your local legislation applicable to the use of this product. Should you need any further information please contact us.